

Cleaning the Gun (Daily)

- 1. Detach** air, resin, and FAC lines from the gun.
- 2. Hook up** the gun flusher adapter to the resin and FAC hookups.
- 3. Hook up** the hose to the gun flusher adapter.
- 4. Open** the spray water valve on the hose.
- 5. Flush** the gun into a bucket for about 5 minutes with hot water.
- 6. Remove** the gun's cone and spinner assembly and clean thoroughly.
- 7. Shut off** spray the nozzle valve and remove the hose adapter from gun.
- 8. Reattach** sprayer to the hose, then rinse off outside of gun and button.
- 9. Roll up** hoses and hang up gun. *Be sure to hang the gun cone down.*
- 10. Shut off/close** the following: Generator, Propane Valve, and Water.

